

System Requirements

- *1GHz or higher CPU*
- *1GB or more RAM*
- *Hard disk with 2GB or more spare space*
- *USB 2.0/3.0*

The software supports the following operating systems:

- *Microsoft Windows Vista*
- *Microsoft Windows 7*
- *Microsoft Windows 8*
- *Microsoft Windows 10*


If the operating system is lower than the above version, please update the system first.

Installation

1. *Insert the installation CD into the CD-ROM of a computer.*
2. *The installation interface pops up. (If no installation interface appears, double-click Setup.exe in the CD-ROM directory to start it manually.)*

Using the Software


1. Interface



Area	Description
1	Toolbar
2	Real-time measurement
3	Control commands
4	Data record
5	Data chart

2. Connecting device

- Click  and select port type.



- If the connection is successful, the measurement data will be displayed in Area 2 and Area 4.


3. Disconnect



- Click  Disconnect
- Each area will stop displaying measurement data


4. Export



- Click  in area 4 to export the data record to an Excel file


5. Clear data




- Click  to clear the recorded data.

6. Setup software



- Click  Options to open options dialog




- “Sample Points”: Set the number of sampling points. If “Infinite” is checked, the number is unlimited

7. Get help



- Click  Manual to open the “Software user manual”

8. Close the software

- Click  to close the software